

BDG Alternator Wiring Guide

Jondel
RACE ENGINES

jondelrace@aol.com

01933 411993

General Information

- “B+” Terminal:
The output terminal connects to positive (+) battery terminal.
- “L” or “D+” Terminal:
The lamp terminal can serve as a current source, sink or both, depending on how it is connected. The diagram shows the standard configuration. Current capability is 0.5 amps for either configuration.
- “W” Terminal:
Not connected.

